

Countdown 3 Schematic

BC327 PNP digit drivers

- S1 = Start/Stop pushbutton
- S2 = Set pushbutton
- S3 = Select pushbutton

